

## How to update the firmware

- Download the latest firmware and save it on your local disk.
- Turn on your external drive and connect it to your computer via **USB**.
- For Mac users, open the \*.dmg file to mount the folder and then double-click on **Setup** to start the updater utility.  
For PC users, unzip the downloaded file and double-click on the \*.exe file to start the updater utility.
- Wait until the device has been recognized by the updater utility.



Click **Upgrade** to start the firmware update.



Wait for the update process to complete and make sure never to turn off the power during the firmware update procedure!



When the upgrade is completed, click **Exit** to close the program. After the firmware update, the system will restart by itself to load the new firmware, so the device will be disconnected and mounted again.



Done!